





VIPER CRAWL SPACE VAPOR BARRIER PINS ARE THE BEST WAY TO SECURE VIPER CS, VIPERS CSX AND INSUL-BARRIER TO MASONRY WALLS.

PRE-DRILL WITH A 1/4" MASONRY BIT, INSERT VIPER PINS AND DRIVE INTO PLACE WITH A MALLET OR HAMMER.

VIPER PINS PROVIDE A STRONG MECHANICAL ATTACHMENT IN CONCRETE BLOCK, BRICK, STONE OR POURED-IN-PLACE CONCRETE.





- FOR USE WITH VIPER CS,
  VIPER CSX OR INSUL-BARRIER
- PRE-DRILL WITH A 1/4" MASONRY BIT
- SUPERIOR HOLD STRENGTH IN MASONRY SUBSTRATES
- 250/BAG 10 BAGS/BOX



